

3.2 User Programming (Manager Programming) Date and Time Set

000

NOTICE

It is assumed that you have read Section 3.1 "General Programming Instructions." The use of the soft buttons is discussed in the section, therefore we will not make any reference to them in the following instructions. At any time the soft buttons can be used in place of the overlay keys.

Description

Sets the current data and time.

Selection

- Day: **1 through 31**
- Month: **Jan. through Dec.**
- Year: **00 through 99**
- Day of the week: **SUN / MON / TUE / WED / THU / FRI / SAT**
- Hour: **00 through 12**
- Minute: **00 through 59**
- **AM / PM**

Default

1 Jan '94 SAT 12:00 AM

FIRST !□

Hit the "Program" key then * * 1 2 3 4

Programming

1. Enter **000**.

Display: Day/Time Set

2. Press **NEXT**.

Display example: 1 Jan '94 SAT

3. Enter the **day**.

To change the current entry, press **CLEAR** and the new day.

4. Press **➡**.

5. Keep pressing **SELECT** until the desired month is displayed.

6. Press **➡**.

7. Enter the **year**.

To change the current entry, press **CLEAR** and the new year.

8. Press **➡**.

9. Keep pressing **SELECT** until the desired day of the week is displayed.

10. Press **STORE**.

11. Press **NEXT**.

Display example: 12:00 AM

12. Enter the **hour**.

To change the current entry, press **CLEAR** and the new hour.

13. Press **➡**.

14. Enter the **minute**.

To change the current entry, press **CLEAR** and the new minutes.

15. Press **➡**.

16. Press **SELECT** for AM or PM.

17. Press **STORE**.

18. Press **END**.

Conditions

- After changing an entry, you can press **STORE**. You do not have to perform all of the rest of the steps.
- To go back to the previous field, press **←** at steps 4 through 9 and steps 13 through 16.
- If you hear the alarm after pressing **STORE**, check that the date is valid.
- The clock starts immediately after the **STORE** button is pressed.
- You cannot leave the entry empty.
- The time is adjusted automatically, if the first outgoing call is made after three o'clock each morning.

Feature References

Installation Manual, Section 3, Features,
Display, Time and Date

Delta Communications (Aust) Pty Limited ☐ Ph: 02 6884 6868 ☐ Fx: 02 6884 3512 ☐ E-mail: scott@deltacommunications.com.au ☐ Web: www.deltacommunications.com.au
--