

How to put your KX-T7633 / 7630 handset in / out of Headset Mode

- 1) Hit the key under "PROG" you will find "PROG" in the screen.
- 2) Dial "6" "1" on the key pad, screen should now say "61:Headset Mode".
- 3) Hit the key under "ENTER" you will find "ENTER" in the screen, screen should now read "Headset Mode Off (or On)"
- 4) Hit the key under "SEL" to toggle between "Headset Off" and "Headset On"
- 5) Once you have SElected in 4) as above, hit the key under "ENTER" you will find "ENTER" in the screen.
- 6) Now to Exit programing Hit the key under "EXIT" you will find "EXIT" in the screen

If you have an problems, please call me.

Scott Layton

Telephone Systems and Data Network Consultant

Delta Communications est. 1982

Phone: (02) 6884 6868

Fax: (02) 6884 3512

Mobile: 0418 84 6868

P.O Box 4266 Dubbo NSW 2830

scott@deltacommunications.com.au

Skype = Deltacommunications